

CIPET WALL PANEL - INSTALLATION

CIPET ACOUSTIC WALL PANEL CAN BE EASILY SCREWED OR PASTED WITH AN ADHESIVE OVER EXISTING WALL OR ANY FRAMEWORK.

OPTION- 1 INSTALLATION WITH ADHESIVE

CIPET Wall Panel can be affixed to the wall using good quality construction adhesive, as follows:

1. Clean the surface & remove surface imperfections/loose particles to enable greater bonding of the adhesive
2. Mark the location of each panel on the wall
3. Apply adhesive using spray gun or by brush smoothly on the back of the panel and on the wall
4. Carefully align the wall panels on the marked location on the wall and press the panel against the wall till it is fixed tightly.



OPTION- 2 INSTALLATION WITH SCREW :

1. Mark the location of each panel on the wall
2. Carefully align the wall panels on the marked location, screw near to edges of the panel, Apply same colour paint on the face of screw.